


## Safety Precaution


- **Important:** Installers and users are obliged to familiarise themselves with this manual.
- **Danger:** Power Cables and plugs have high voltage from the battery, be careful when wiring.
- **Important:** Ensure that a fire extinguisher is in place prior to installation and use.
- **Warning:** Installation and operation must be carried out by qualified personnel and the system must be installed in restricted access areas.
- **Caution:** The battery module is with certain weight, it is recommended to be installed by at least two people. With the help of tools if necessary.

## Contents in SIMPO HV Package


### Battery Package:



### BMS Package:



### Accessories Included:



## Extra Accessories

Extra accessories are not included in the accessory box but necessary for system build up.



DC Cables  
(≥8 AWG)



PE Cable with T  
terminal (SC10-5)  
(≥ 8AWG)



COM Cable  
(Cat.5 or Upper)

## Tools



Insulated gloves



Screwdriver



Safety Shoes



Drill



Multimeter



Crimper



Torque Wrench



Wire Cutter



Utility Knife




Wrench




Spirit Level

## Different Functional Area on BMS



Letter	Lable	Function
A	-	DC-
B	+	DC+
C	ETH	Ethernet
D	OUT	Com Out
E	HMI	Human Machine Interface
F	ON/FF	ON/OFF
G	INV	Inverter COM
H	PE	PE Connection
I	IN	COM In
J	/	Circuit Breaker


## Place the base



- The base should be based on solid floor.
- A spirit level is recommended for use when adjusting the feet.


## Position of Fixing Parts

Number ①-⑨ represent module sequence only in this part.




Module Qty per Tower	Position of module fixing parts	Height of Module Perforation	Height of BMS Perforation
2	NONE	NONE	475 mm
3	③	H1=591 mm	665 mm
4	④	H1=781 mm	855 mm
5	③&⑤	H1=591 mm H2=969 mm	1045 mm
6	③&⑥	H1=591 mm H2=1160 mm	1235 mm
7	③&⑦	H1=591 mm H2=1351 mm	1425 mm
8	③&⑥&⑧	H1=591 mm H2=1160 mm H3=1541 mm	1731 mm
9	③&⑥&⑨	H1=591 mm H2=1160 mm H3=1731 mm	1803 mm

## Power Cables Crimping




## Fix To The Wall


### Fix Modules




#### Step 1



#### Step 2




#### Step 3




### Fix BMS


#### Back view




#### Step 1



#### Step 2




#### Step 3





## Cables Connection


## System Overview:




## PE Cables Connection:



## Power Cables Connection:




## Communication Cables Connection:



## Definition of SIMPO HV "INV" Port

PIN NO.	1	2	3	4	5	6	7	8
Definition	11VGND	12V	11V	CAN_H	CAN_L	12VGND	RS485B	RS485A


## Parallel Multiple Towers



## Note:


- When parallel multiple towers ( $\leq 8$ ) only the 'Set On' LED on master is ON.
- Only the 'Last Unit' LED of last tower (N) is ON.

## Human Machine Interface (HMI)




## Connection With Inverters


## Connecting with Kostal Plenticore Plus/Plenticore BI




## Connecting with Kostal Piko MP Plus



## Connecting with GoodWe Inverters




## Start Up



- Turn on the **DC breaker** between battery and inverter (if any).
- Turn on the **Air Switch**.
- Press '**ON/OFF**' to start the system.

## Connect to Internet &amp; ZYC Portal &amp; ZYC Assist



## There are two options to connect to the internet with SIMPO WIFI

- Connect SIMPO WIFI to the router directly with a network cable.
- Set up a wireless connection for SIMPO WIFI through ZYC Assist APP.

When the app is connecting with the hotspot of the SIMPO WIFI, follow the below steps:

Open ZYC Assist APP → Others → Connect to Internet → Fill in the WiFi name and password of Router